



E-TREAT DRINKING WATER SYSTEM



Stage 1 Sediment	Stage 2 Carbon	Stage 3 UF
------------------------	----------------------	------------------

E-TREAT DRINKING WATER SYSTEM

Enjoy safe, high quality, great tasting drinking water. The E-Treat Drinking Water System is the ideal, low cost alternative to reverse osmosis systems. Simple and easy to maintain with quick twist and lock cartridges allowing you to change the cartridges without the mess.

Proven Ultra-Filtration technology ensures clean & safe drinking water without the hassle of transporting bottles or running out of water. The E-Treat system filters out contaminants, chlorine, tastes, odors, particulates, and micro-organisms from your water.

The E-Treat system can be installed underneath your kitchen sink and can be connected to your refrigerator or installed on drinking water fountains.

Features

- * Simple and Easy Installation
- * Easy to Maintain
- * Hollow Fiber UF Technology
- * No Waste Water
- * Saves Space
- * No Storage Tank
- * No Pressure Loss
- * Includes Installation Kit with Faucet



3 STAGE FILTRATION PROCESS:

Stage 1: Sediment Cartridge

Removes particulate, sand, silt, rust particles, and other solid matter

Stage 2: Activated Carbon Cartridge

Reduces chlorine, taste odors, and other potentially harmful contaminants

Stage 3: Hollow Fiber Ultra-Filter Cartridge

Reduces potentially harmful microorganisms

SOLUTIONS * SERVICE * SUPPORT

Better Water LLC; 698 Swan Dr; Smyrna, TN 37167; Phone (615) 355-6063, Fax (615) 355-6065
Website www.betterwater.com

rev. May 2016



Equipment changes are at the sole discretion of Better Water LLC.
Brochure photographs and specifications may not reflect recent changes.