



QUICK CHANGE UF DRINKING WATER SYSTEM



QUICK CHANGE UF DRINKING WATER SYSTEM

Enjoy safe, high quality, great tasting drinking water. The Quick-Change UF Drinking Water System is certified to NSF/ANSI Standards 42 & 53 and is WQA Gold Seal certified. Simple and easy to maintain with quick twist and lock cartridges allowing you to change the cartridges without the mess.

Proven Hollow Fiber Ultra-Filtration technology ensures clean & safe drinking water without the hassle of transporting bottles or running out of water. The E-Treat system filters out contaminants, chlorine, tastes, odors, particulates, and micro-organisms from your water.

The Quick Change system can be installed underneath your kitchen sink and can be connected to your refrigerator or installed on drinking water fountains.

Features

- * Simple and Easy Installation
- * Easy to Maintain
- * Hollow Fiber UF Technology
- * No Waste Water
- * Saves Space
- * No Storage Tank
- * Little Pressure Loss
- * Includes Installation Kit with Faucet



3 STAGE FILTRATION PROCESS:

Stage 1: Sediment Cartridge

Removes particulate, sand, silt, rust particles, and other solid matter

Stage 2: Activated Carbon Cartridge

Reduces chlorine, taste odors, and other potentially harmful contaminants

Stage 3: Hollow Fiber Ultra-Filter Cartridge

Reduces potentially harmful microorganisms

SOLUTIONS * SERVICE * SUPPORT

Better Water LLC; 698 Swan Dr; Smyrna, TN 37167; Phone (615) 355-6063, Fax (615) 355-6065
Website www.betterwater.com

rev. May 2016



*Equipment changes are at the sole discretion of Better Water LLC.
Brochure photographs and specifications may not reflect recent changes.*