



Better Water LLC

Clean In Place Plus



Standard Features

- * 40 Gallon, Cone Bottom
- * Pressure Gauge
- * Product and Reject Ports
- * Easily visible graduation lines for measuring
- * Durable pump rated at 1/2 horsepower
- * Standard 115 VAC power
- * Easy roll casters with easy to use safety locks

CLEAN IN PLACE PLUS

- Better Water LLC's Clean In Place is designed with the end-user in mind.
- This unit combines portability with features users have requested and will appreciate.
 - Durable
 - Low Maintenance
 - Light Empty Weight
- Comes with three hoses:
 - Supply Hose
 - Product Hose
 - Reject Hose
- 40 gallon, cone-bottom, polyethylene tank which provides a lower center of gravity and ensures all the mixture is accessible. The tank also has graduation marks on the side to assist with measuring.
- The top includes an 8" vented, removable lid for ease in adding cleaning and disinfecting chemicals.

SOLUTIONS * SERVICE * SUPPORT

Better Water LLC; 698 Swan Dr; Smyrna, TN 37167; Phone (615) 355-6063, Fax (615) 355-6065
Website www.betterwater.com

rev. Dec 2012



*Equipment changes are at the sole discretion of Better Water LLC.
Brochure photographs and specifications may not reflect recent changes.*





Better Water LLC

Clean In Place Plus

Models and Specifications

Model	EQCLEANSTATIONPLUS
Tank Capacity	40 Gallons
Tank	Medium density Polyethylene, cone bottom
Tank Dimensions	30 x 34 inches
Approximate Dimensions	31" width x 56" height
Empty Weight	117 lbs
Weight w/30 Gallons of Water	367 lbs
Pump	1/2hp, 115vac , 60hz, 10.8 amps
Pump Performance	5gpm@30psi, 20gpm@28psi, 47gpm@14psi
Pump Wetted Materials Construction	Noryl, 300 series stainless steel, carbon/ceramic and Viton
Frame	Welded steel coated with corrosion resistant paint
Supply Hose	7ft x 1" PVC nylon reinforced hose with Park quick disconnects
Product Reject Hose	6ft x 3/4" PVC nylon reinforced hose with Park quick disconnect
Suction Hose	PVC reinforced ball valves and fittings polypropylene or polypropylene reinforced
Pressure Bypass	Wetted parts, nylon, 300 series stainless steel, Fairprene, 3/4" npt connections
Regulated Pressure Gauge	2.5" dial 1/4" npt, bottom mount, 300 series stainless steel wetted parts

SOLUTIONS * SERVICE * SUPPORT

Better Water LLC; 698 Swan Dr; Smyrna, TN 37167; Phone (615) 355-6063, Fax (615) 355-6065
Website www.betterwater.com

rev. Dec 2012



*Equipment changes are at the sole discretion of Better Water LLC.
Brochure photographs and specifications may not reflect recent changes.*

